




STEAM GENERATOR

VAPOR OK-4625-74



OPERATING MANUAL

OFFICE OF THE CHIEF MECHANICAL OFFICER
400 N. CAPITOL ST.,
WASHINGTON, D.C. 20001

NRPC CMO-115 (10-77)

AMTRAK STEAM GENERATOR (VAPOR CORP. OK-4625-74G)

OPERATING MANUAL

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
0.	INTRODUCTION	1
10.	GENERAL SPECIFICATION DATA	3
10-1	RH Steam Generator Front View	
10-2	LH Steam Generator Right Side View	
10-3	LH Steam Generator Left Side View	
10-4	LH Steam Generator Rear View	
100.	NORMAL OPERATION	4
101.	Filling Procedure	4
102.	Starting Procedure	6
103.	Shut-Down Procedure	9
104.	Cold Weather Protection Procedure	12
200.	ABNORMAL OPERATION	13
201.	Superheating	13
202.	Hot Dome	14
203.	Safety Valves Popping	14
204.	Motor Speed Variations	14
205.	Poor Steam Output	14
300.	TROUBLESHOOTING PROCEDURES	15
400.	EMERGENCY PROCEDURES	22
500.	APPENDIX	28
	Figure	Title
500-1	Piping Diagram	29
500-2	Electrical Schematic Diagram	30
500-3	Valve Position Guide	31

10. GENERAL SPECIFICATION DATA

VAPOR OK-4625-74-G STEAM GENERATOR

Water Relief Valve—
unloading setting 575 PSI.

Fuel Pressure Regulator—
set at high fire to give
manifold pressure of 150-155 PSI.

Atomizing air pressure 70-75 PSI (at 130-140
PSI main reservoir pressure—with #51 drill orifice).

Atomizing Air Pressure Switch Settings. Contacts close at
55 PSI. Contacts open at 45 PSI.

Water Pressure (Fill Position) Normal—less
with #4 valve fully opened. than 80 PSI.

Water Pressure Range (low
to high fire) 225-350 PSI.

Normal Steam Temperature,
at 200 PSI pressure 388°F.

Steam Temperature Limit (STL)
Control—operates at
approximately 500-600°F.

Stack Switch Settings
High temperature contacts open at 900°F.
Low temperature contacts close at 250°F.

Outfire Relay—time delay is 43-47 sec.

Motor Speed (high fire) 1750-1800 RPM.

Blower Speed (high fire) 2500-2550 RPM.

Water Pump Speed (high fire) 915-935 RPM.

Amperage Draw (74 VDC) 45-55 amperes.

Motor Overload Dashpot—
set to trip at 82-84 amperes.

Maximum Evaporate
Capacity (high fire) 347 gallons/hour.

Fuel Consumption at maximum
output 30 gallons/hour.

Water Volume (coils and
related piping) 24.5 gallons.

Dry Weight 4000 lbs. net.

100. NORMAL OPERATION

1. Make sure water tanks are **full** before leaving servicing point.



WARNING: DO NOT START STEAM GENERATOR UNLESS THE COILS ARE FILLED WITH WATER.

2. Refer to Valve Position Guide (Figure 500-3) for proper valve positions for all modes of operation.

[illegible]

The component identification numbers shown in parentheses in the following procedures are indexed on the piping diagram (Figure 500-1) in the rear of this manual. Valves are similarly identified on the piping diagram (Figure 500-1) and on the Valve Position Guide (Figure 500-3) at the rear of this manual and in each locomotive steam generator room.

101. FILLING PROCEDURE

1. Open fill test valve # 4.



2. The following valves must be **closed** to properly fill the steam generator. Refer to Figure 500-1 as a reference:
 - A. Trainline Shut-off #15. **Close** by manually turning valve handle **down**;
 - B. Roof Orifice #273 turn handle clockwise (CW) to close;
 - C. Separator Blow down #12. Valve is closed when pedal latching pin is **not** engaged under latching block and the pedal is floating freely.

3. Check the following **reset** buttons by pushing in:
- A. Motor Overload (106):



- B. Stack Switch (109): and



- C. Steam Temperature Limit Switch (110) (if equipped with **reset**). Refer to Figure 10-2 for switch location.

4. Turn main switch ON or close Main Circuit Breaker; located adjacent to each steam generator (E-8, E-9 loco) or top center of water deck tank (SD P-40 F loco).



5. Turn Control Switch (102) to FILL. If generator does not run, refer to Trouble Shooting Procedures—Section 300.





CAUTION: DO NOT TOUCH ANY PART OF THE IGNITION WIRING

6. Check for ignition spark by looking into the spray head sight glass for a bright blue arc at electrodes (220).



7. Turn Control Switch OFF when a strong flow of water is discharging from Fill Test Valve #4. Allow the servo "bow-tie" to return to the block so a smooth light-off will occur during starting. Servo is shown in OFF position.



8. Close Fill Test Valve #4.



102. RUN PROCEDURE

1. Refer to **Valve Position Guide** for proper valve positions (Figure 500-3).


STEAM GENERATOR VALVE POSITION GUIDE

Valve	Position	Notes
1. FILL TEST VALVE #4	CLOSE	
2. SEPARATOR BLOWDOWN VALVE #12	OPEN	
3. STEAM TEMP LIMIT SWITCH (110)	CLOSE	
4. WATER BY-PASS REGULATOR (111)	230 PSI	
5. CONTROL SWITCH	RUN	
6. SERVO "BOW-TIE"	HIGH FIRE	
7. PRESSURE GAUGE (212)	100 PSI	
8. SEPARATOR BLOWDOWN VALVE #12	OPEN	

See Figure 500-3 at rear of manual

2. Before starting steam generator, perform filling procedure (Section 101 above).

3. Insure #10 Valve is tightly **closed** to prevent tripping the Steam Temp Limit Switch (110) while generator is operating. See note on Valve Position Guide (500.3) under Amtrak Standard.
4. Set Water By-pass Regulator (111) to 230 PSI.



5. Open Separator Blowdown Valve #12 by pressing down on foot pedal and allowing latching pin to engage under latching block.



6. Turn Control Switch to RUN; generator should fire. Servo "bow-tie" should move clockwise to **high fire** position. If generator does not run, refer to Trouble-shooting Procedures—Section 300.



7. Close Separator Blowdown Valve #12 when steam pressure gauge (212) reaches 100 PSI.



8. Press down pedal on Separator Blowdown Valve and hold open for 3-5 second intervals during the first few minutes of operation.

9. During normal running mode, the Flapper in the Water Return Sight Glass should cycle 4 to 8 times per minute. If an abnormal condition exists, refer to **Abnormal Operation and Troubleshooting Procedures**, Sections 200 and 300 respectively.

10. Make sure Automatic Trainline Shut-off Valve #15 is **manually closed** before trainline is coupled. Valve handle must be screwed **down** to close.



11. When trainline coupling has been completed and all ground forces are clear.

12. Push "**open**" button for Automatic Trainline Shut-off Valve on Valve Controller (270), if unit is so equipped. Air pressure should be heard exhausting through magnet valve.



13. **Manually open** the Trainline Shut-off Valve #15 **slowly** by screwing **up** on valve handle. Do not allow steam generator pressure gauge (2-12) to fall below 100 PSI; if valve is operated too fast STL Switch (110) may trip and shut down the generator.



14. Observe Trainline Pressure Gauge (224) (if so equipped) or steam generator pressure gauge (212) and **OPERATE ONLY** the number of steam generators **REQUIRED** to maintain 180 to 250 PSI trainline pressure. Trainline pressure is the guide to determine the maximum number of generators that must be operating to satisfy any given train.

The key to good steam generator performance is to MAKE THE GENERATOR WORK; DON'T LET IT IDLE.


103. SHUT-DOWN AND BACK-BLOW PROCEDURE

1. Refer to **Valve Position Guide** (Figure 500-3) for proper valve positions.

STEAM GENERATOR VALVE POSITION GUIDE

VALVE	START	STOP	SHUT-DOWN	BACK-BLOW
1. Main Steam Valve	Open	Open	Open	Open
2. Main Steam Stop Valve	Open	Open	Open	Open
3. Main Steam Bypass Valve	Open	Open	Open	Open
4. Main Steam Isolation Valve	Open	Open	Open	Open
5. Main Steam Control Valve	Open	Open	Open	Open
6. Main Steam Stop Valve	Open	Open	Open	Open
7. Main Steam Bypass Valve	Open	Open	Open	Open
8. Main Steam Isolation Valve	Open	Open	Open	Open
9. Main Steam Control Valve	Open	Open	Open	Open
10. Main Steam Stop Valve	Open	Open	Open	Open
11. Main Steam Bypass Valve	Open	Open	Open	Open
12. Main Steam Isolation Valve	Open	Open	Open	Open
13. Main Steam Control Valve	Open	Open	Open	Open
14. Main Steam Stop Valve	Open	Open	Open	Open
15. Main Steam Bypass Valve	Open	Open	Open	Open
16. Main Steam Isolation Valve	Open	Open	Open	Open
17. Main Steam Control Valve	Open	Open	Open	Open
18. Main Steam Stop Valve	Open	Open	Open	Open
19. Main Steam Bypass Valve	Open	Open	Open	Open
20. Main Steam Isolation Valve	Open	Open	Open	Open
21. Main Steam Control Valve	Open	Open	Open	Open
22. Main Steam Stop Valve	Open	Open	Open	Open
23. Main Steam Bypass Valve	Open	Open	Open	Open
24. Main Steam Isolation Valve	Open	Open	Open	Open
25. Main Steam Control Valve	Open	Open	Open	Open
26. Main Steam Stop Valve	Open	Open	Open	Open
27. Main Steam Bypass Valve	Open	Open	Open	Open
28. Main Steam Isolation Valve	Open	Open	Open	Open
29. Main Steam Control Valve	Open	Open	Open	Open
30. Main Steam Stop Valve	Open	Open	Open	Open
31. Main Steam Bypass Valve	Open	Open	Open	Open
32. Main Steam Isolation Valve	Open	Open	Open	Open
33. Main Steam Control Valve	Open	Open	Open	Open
34. Main Steam Stop Valve	Open	Open	Open	Open
35. Main Steam Bypass Valve	Open	Open	Open	Open
36. Main Steam Isolation Valve	Open	Open	Open	Open
37. Main Steam Control Valve	Open	Open	Open	Open
38. Main Steam Stop Valve	Open	Open	Open	Open
39. Main Steam Bypass Valve	Open	Open	Open	Open
40. Main Steam Isolation Valve	Open	Open	Open	Open
41. Main Steam Control Valve	Open	Open	Open	Open
42. Main Steam Stop Valve	Open	Open	Open	Open
43. Main Steam Bypass Valve	Open	Open	Open	Open
44. Main Steam Isolation Valve	Open	Open	Open	Open
45. Main Steam Control Valve	Open	Open	Open	Open
46. Main Steam Stop Valve	Open	Open	Open	Open
47. Main Steam Bypass Valve	Open	Open	Open	Open
48. Main Steam Isolation Valve	Open	Open	Open	Open
49. Main Steam Control Valve	Open	Open	Open	Open
50. Main Steam Stop Valve	Open	Open	Open	Open
51. Main Steam Bypass Valve	Open	Open	Open	Open
52. Main Steam Isolation Valve	Open	Open	Open	Open
53. Main Steam Control Valve	Open	Open	Open	Open
54. Main Steam Stop Valve	Open	Open	Open	Open
55. Main Steam Bypass Valve	Open	Open	Open	Open
56. Main Steam Isolation Valve	Open	Open	Open	Open
57. Main Steam Control Valve	Open	Open	Open	Open
58. Main Steam Stop Valve	Open	Open	Open	Open
59. Main Steam Bypass Valve	Open	Open	Open	Open
60. Main Steam Isolation Valve	Open	Open	Open	Open
61. Main Steam Control Valve	Open	Open	Open	Open
62. Main Steam Stop Valve	Open	Open	Open	Open
63. Main Steam Bypass Valve	Open	Open	Open	Open
64. Main Steam Isolation Valve	Open	Open	Open	Open
65. Main Steam Control Valve	Open	Open	Open	Open
66. Main Steam Stop Valve	Open	Open	Open	Open
67. Main Steam Bypass Valve	Open	Open	Open	Open
68. Main Steam Isolation Valve	Open	Open	Open	Open
69. Main Steam Control Valve	Open	Open	Open	Open
70. Main Steam Stop Valve	Open	Open	Open	Open
71. Main Steam Bypass Valve	Open	Open	Open	Open
72. Main Steam Isolation Valve	Open	Open	Open	Open
73. Main Steam Control Valve	Open	Open	Open	Open
74. Main Steam Stop Valve	Open	Open	Open	Open
75. Main Steam Bypass Valve	Open	Open	Open	Open
76. Main Steam Isolation Valve	Open	Open	Open	Open
77. Main Steam Control Valve	Open	Open	Open	Open
78. Main Steam Stop Valve	Open	Open	Open	Open
79. Main Steam Bypass Valve	Open	Open	Open	Open
80. Main Steam Isolation Valve	Open	Open	Open	Open
81. Main Steam Control Valve	Open	Open	Open	Open
82. Main Steam Stop Valve	Open	Open	Open	Open
83. Main Steam Bypass Valve	Open	Open	Open	Open
84. Main Steam Isolation Valve	Open	Open	Open	Open
85. Main Steam Control Valve	Open	Open	Open	Open
86. Main Steam Stop Valve	Open	Open	Open	Open
87. Main Steam Bypass Valve	Open	Open	Open	Open
88. Main Steam Isolation Valve	Open	Open	Open	Open
89. Main Steam Control Valve	Open	Open	Open	Open
90. Main Steam Stop Valve	Open	Open	Open	Open
91. Main Steam Bypass Valve	Open	Open	Open	Open
92. Main Steam Isolation Valve	Open	Open	Open	Open
93. Main Steam Control Valve	Open	Open	Open	Open
94. Main Steam Stop Valve	Open	Open	Open	Open
95. Main Steam Bypass Valve	Open	Open	Open	Open
96. Main Steam Isolation Valve	Open	Open	Open	Open
97. Main Steam Control Valve	Open	Open	Open	Open
98. Main Steam Stop Valve	Open	Open	Open	Open
99. Main Steam Bypass Valve	Open	Open	Open	Open
100. Main Steam Isolation Valve	Open	Open	Open	Open

2. Push "**Close**" button on #15 Valve Controller (270) if so equipped.



3. Manually close #15 Valve. Screw Valve handle down to close.



4. Set Water Bypass Regulator (111) to maximum PSI position. Allow steam pressure to build up to maximum.



5. When fire shuts OFF turn Control Switch (102) OFF.



6. Immediately OPEN Coil Blowdown Valve #2.



7. When steam pressure drops to 75 PSI, CLOSE #2 Valve.



8. OPEN Separator Blowdown Valve #12.



9. Turn Control Switch to FILL and allow steam generator to fill for approximately 5 minutes.




10. OPEN Fill Test Valve #4, then



11. CLOSE #12 Separator Blowdown Valve.



12. Wait for strong flow of water to discharge from Fill Test Valve #4.




13. Turn Control Switch OFF. Close Fill Test Valve #4.



14. Close Atomizing Air Valve #1.



15. Turn main switch OFF.



16. After the steam generator is shut down, the following steps in Section 104 **must be taken to prevent freeze-up in cold weather.**

104. COLD WEATHER PROTECTON

1. Refer to the **Cold Weather Protection** column of the **Valve Position Guide** (Fig. 500-3). See Note below.
2. Make sure Cold Weather protection valves are **opened** on all generators which are shut down. See step 5A or-B below.
3. If standby steam is not available, locomotive main engine must be idling and one steam generator operating.
4. If **more than one steam generator is in the consist, the Trainline Shut-off Valve #15 must be opened** on the generator that is operating and the locomotive trainline **End Valves** must be **cracked open** to prevent trainline freeze-up.

NOTE: Some locomotives are equipped with the two-valve (#6 & #10) Cold Weather Protection System. Refer to step 5B and the **Valve Position Guide** (Figure 500-3) for explanation.

5. Valve set up for Cold Weather protection on steam generator ...
 - A. One-valve system. (#10 only)
 - (1) Open #10 valve.
 - (2) **CHECK SYSTEM OPERATION BEFORE LEAVING LOCOMOTIVE;** tracer and inlet coil lines should be hot to touch. Flapper Valve in Water Return Sight Glass must be opening intermittently and water return line should be hot to touch.
 - B. Two-Valve system. (#6 & #10);
 - (1) Open #6 valve.



- (2) Open #10 valve.
- (3) **CHECK SYSTEM OPERATION BEFORE LEAVING LOCOMOTIVE;** tracer and inlet coil lines should be hot to touch. Flapper Valve in Water Return Sight Glass must be opening intermittently and water return line should be hot to touch.



- (4) #10 valve may be cracked open during operation.

200. ABNORMAL OPERATION

If abnormal conditions are encountered, make a written report to responsible maintenance personnel using **prescribed** forms on locomotive. Describe the condition as much as possible.

201. SUPERHEATING

Overheated steam may be causing the Steam Temperature Limit Switch (110) to shut off the fire. This condition can be detected when in the running mode by observing that the servo "bow tie" is in the **high fire** position with no fire present.

1. Check Water Return Sight Glass for proper water return. Flapper Valve in glass should open and close approximately 4 to 8 times per minute.
2. The **STL** Switch is faulty if the water return is normal as indicated by movement of the Flapper Valve 4-8 times per minute and generator is continuing to trip the **STL** Switch (110). If Flapper Valve remains open, this indicates a leaking Heat Exchanger (213). Close #81 valve and continue operating. With #81 valve closed Flapper Valve will stop moving.
3. Check for water leak at outlet of Coil Blowdown Valve #2 by **CAREFULLY** touching the valve discharge pipe. If pipe is warm or hot, it indicates #2 valve is leaking. Reduce steam output by cracking Valve #8. Refer to **Manual Operation** column of **Valve Position Guide**. (Figure 500-3)
4. Excessive fuel pressure may also be the cause of tripping the **STL** Switch (110). Reduce output by cracking #8 valve. Refer to **Manual Operation** column of **Valve Position guide**. (Figure 500-3)
5. On a One-Valve Cold Weather Protection System, make sure that the #10 valve is **tightly closed**. On a two-valve system, insure that the #6 valve is **tightly closed**.

NOTE: When the **STL** Switch trips, the steam generator will continue to run for three to four minutes until the low contacts of the **Stack Switch** open. When this occurs the alarm will ring and the motor will stop.

202. HOT DOME

An overheated Steam Generator Dome is usually the result of a reduction in the amount of combustion air delivered to the generator. If this occurs, inspect the Damper (203) and Damper Spring for binding. Make sure there are no restrictions, such as ice or debris in the air intake ducting, or soot on the coils. Check the tension of the Blower Belts with care. The speed of the Blower (202) should be 2500 RPM. Reduce output by cracking #8 valve. Refer to **Manual Operation** column of **Valve Position Guide**. (Figure 500-3)

203. SAFETY VALVES POPPING

The Water By-Pass Regulator (111) is not controlling steam pressure. Be sure Valves #13 and #19 are **open**. Check the Regulator for ruptured diaphragm. If steam blows from regulator, close #13 Valve. Also check for sticking operating rod or restrictions in the pipe between the #13 valve and the Regulator. Continue to operate the steam generator **manually**. Refer to **Manual Operation** column of **Valve Position Guide**. (Figure 500-3).

204. MOTOR CONVERTER SPEED VARIATION

- (1) Speed Very High.
If voltage is normal (72-74 VDC), extremely high motor speed may be due to an open field circuit. Check electrically for open Field Resistor. If this is the case, jumper out the resistor. (If so equipped).
- (2) Speed Very Low.
If voltage is normal, the motor may be operating through the Starting Resistor. This can be caused by an open circuit in the coil of the Pilot Relay or its contacts, or in the Timing Resistor.

205. POOR STEAM OUTPUT

Control Switch (102) must be in RUN. Check for any condition which may reduce the amount of fuel burned or restrict heat transfer from the fire to water, such as coils sooting, high water pressure (caused by internal coil scaling), #8 valve being cracked open or ruptured servo diaphragm. Perform procedure shown under Troubleshooting Procedures Section 300.

300. TROUBLESHOOTING PROCEDURES


To use this troubleshooting guide, follow the numbered procedure below (1, 2, etc.). If any lettered (1A, 1B etc.) symptom is applicable, the possible cause and corrective actions (1A1, 1A2, etc.) are listed below each symptom. Also refer to Abnormal Operation Section (200), and Emergency Procedures, Section 400.

1. TURN CONTROL SWITCH TO "FILL" AND CHECK ELECTRICAL SYSTEM AS FOLLOWS:

1A. IF MOTOR STARTS AND BELL DOES NOT RING. GO TO 1A1 BELOW


If motor does NOT start and alarm bell RINGS, go to 1B below.

- 1A1. Control or main power Fuses blown. This will be indicated by the Return Water Sight Glass light not burning. Test fuses located in steam generator electrical cabinet and in the main fuse panel in locomotive cab. If fuse blows again, examine control circuit for short. See Section 400.
- 1A2. Steam Generator main breaker or fuses may be tripped or blown if there is a short circuit in the steam generator motor. Reset this breaker, by pulling **down** on handle, then pushing **up**. Replace fuse if required. See Section 400.



NOTE: SPD-40F locomotives are equipped with 100 AMP fuses. E-8 and E-9's are equipped with circuit breakers.


- 1A3. Circuit may be open in Starting Resistor. (in box behind control panel). This can be the result of bad order Pilot Relay coil or contacts, or open circuit in the Timing Resistor. Control Relay Coil may also be defective. See Section 400.



- 1A4. If Main Steam Generator Breaker or fuses continue to trip or blow, the contacts of the Control Relay may be stuck closed. Also, test Motor (215) electrically for short circuit.
- 1A5. Check armature of Motor (215) electrically for open circuit.
- 1A6. Contacts of Control Switch (102) may not be making electrically due to worn cam or contacts. See Section 400.
- 1A7. Coil or contacts of Line Relay may be open. If so, repair contacts or replace coil. See Section 400.

1B. IF MOTOR DOES NOT START AND ALARM BELL DOES RING.

- 1B1. Motor Overload Relay (106) may be tripped. Push reset button, fill coils and restart unit. Check for proper amount of oil in dash-pot of Motor Overload Relay. If switch opens again, open Valve #8 slightly to reduce the load on the Steam Generator Motor.
- 1B2. Stack Switch Button (109) is pushed out. Reset button and restart unit after filling coils. Open Valve #8 slightly if the switch opens again. See Section 400.



- 1B3. Check for proper latching of Coil Blowdown Valve. Check for open Coil Blowdown Switch circuit.



- 1B4. Check for overtightened belts or bad bearings in Motor (215).
- 1B5. If high temperature causes Stack Switch to open, check coils for heavy sooting or high water pressure due to internal coil scaling. Remove air dome and look for holes in the refractory which may by-pass hot gasses around coils. See Section 400.
- 1B6. Check Outfire Relay indicator light. When light is on this indicates relay contacts are closed. When light is off, it indicates relay contacts are open. Relay Indicating Light should be on anytime the Servo "Bow-Tie" is in the off or No-Fire position. The light should go out approximately 45 seconds after the Servo moves to the firing position. See Section 400.

2. WITH CONTROL SWITCH AT "FILL", CHECK WATER SYSTEM AS FOLLOWS:


If motor starts and Servo "Bow-Tie" is rocking erratically or violently, go to 2B below.

If motor starts and Servo "Bow-Tie" turns smoothly, go to 2C below.

IF MOTOR STARTS AND SERVO "BOW-TIE" DOES NOT MOVE, CHECK FOR THE FOLLOWING:

(Full Servo travel can be expected in FILL position.)

- 2A1. Not enough water to operate "Bow-Tie" or No Fuel Manifold Pressure. (See Fuel System—3A3 below)



Servo will be in the position shown. (No Fire).
Open water pump Test Valve #18.

2A2. If the water flow is strong and steady, follow this procedure:


1. Check to be sure that Manual By-Pass Valve #8 is fully closed.



2. If water pressure is above 100 PSI, be sure Valve #3 is fully open. Back-blow coils several times to clear possible plugging, using the following procedure:

- a. Refer to **Valve Position Guide** for proper valve positions.
 - b. Push **Close** button on #15 valve controller. (If so equipped).
 - c. Manually close #15 Valve. (Screw valve handle down).
 - d. Set Water By-Pass Regulator (111) to maximum PSI position. Allow steam pressure to build up to maximum.
 - e. Turn Control Switch (102) OFF after fire shuts off.
 - f. Immediately OPEN Coil Blowdown Valve #2.
 - g. When steam pressure drops to 75 PSI, CLOSE Valve #2.
 - h. OPEN Separator Blowdown Valve #12.
 - i. Turn Control Switch to FILL and allow steam generator to fill for approximately 5 minutes.
 - j. OPEN Fill Test Valve #4, then ...
 - k. CLOSE Separator Blowdown Valve #12.
 - l. Wait for strong flow of water to discharge from Fill Test Valve #4.
 - m. Turn control switch **Off**. **Close** fill test valve #4 and **Open** Separator Blowdown Valve #12.
 - n. Place Control Switch in **run** position and perform **Starting Procedure** (Section 102 above).
3. Acid wash the coils if possible. High water pressure can also be the result of stuck Feed Line Check Valves or other obstructions.

4. Close Water By-Pass Shutoff Valve #19. If servo "Bow-Tie" (108) moves (CW), Water By-Pass Regulator (111) is leaking. If moving handle of Regulator back and forth several times does not re-seat valve, **then leave Valve #19 closed and operate Steam Generator manually**. If possible, replace Water By-Pass Regulator Valve.



5. Check the Servo Fuel Control (108) for ruptured diaphragm or missing water-metering pin. Replace diaphragm or metering pin if necessary.

2A3. If water flow is weak or absent (as indicated by very slight or no movement of the "Bow-Tie") follow this procedure:

1. Open #18 valve (Water Pump Discharge Valve); check for strong water flow.
2. Check locomotive water tanks for proper water supply by observing gauges or tapping tank with metallic objects, listening for solid (not hollow) sound.
3. Make sure Water Supply Shutoff Valve #21 is open.
4. Be sure Water Treatment Tank Drain Valve #22 is closed.
5. If water supply is too hot (over 180°F.) close #81 valve and open #82 valve. This allows return water to dump overboard.
6. Be sure #6 valve (two-valve cold weather protection system) or #10 valve (one-valve system) are **closed**.
7. Take cover off Water Treatment Tank and see if strainer is plugged. Be sure there is no suction leak in cover seal. Check O-Ring for cuts, breaks or twists. Replace seal or lubricate old seal before reapplying.



8. Check Water Pump Belts for tension and condition.

9. Examine Water Pump valve and valve seats. Check Water Pump (230) piston packing and cylinder liner for dirt or wear.
10. Check feedwater line for suction leaks. Close #21 Valve.
11. Fill Water Treatment Tank with a bucket and run pump to see if it will draw water. If it will, then examine water suction line between treatment tank and water tanks for suction leaks or restriction in suction line.

2B. IF MOTOR STARTS AND SERVO "BOW-TIE" TURNS. FILL COILS WITH WATER AND CONTINUE TO PROCEDURE 3 BELOW.


3. TURN CONTROL SWITCH TO "RUN"

If generator runs normally, go to 3B.


3A. MOTOR STARTS BUT RUNS ONLY 40 TO 60 SECONDS AND FIRE DOES NOT LIGHT. GENERATOR SHUTS DOWN WITH ALARM RINGING.

3A1. Ignition system fault. Fuel spray present but not igniting. Follow this procedure:

1. One of the Electrodes (220) may have twisted out of position. Spark gap should be 3/16" and be just outside but not touching the fuel spray. Reset the Electrodes with a gauge (if available). Position the spark just between two fuel jets. Spray-head (105) should be as deep into combustion chamber as threads will allow.



2. If there is no spark, test ignition fuses with light and fuse clips. Check for burned or loose leads to Electrodes. Check for burned out transformer (214) or loose internal connections (use test meter). Examine the brushes and slip rings in the Motor (215) visually for sticking brushes, pitting, burning, or open ignition circuit.



3A2. Fuel system fault: No fuel spray or poor fuel spray and air pressure is approximately 70 PSI.

1. If Fuel Manifold pressure is below 150 (PSI) turn knife handle of Cuno Filter (206) several times.



2. If Fuel Manifold pressure is still low, check for stuck pressure regulator by tapping lightly. Check for worn fuel pump (209), broken or loose fuel pump coupling. Change fuel pump if possible. Check regulator operation.
3. If there is no Manifold pressure at gauge, check for suction leaks in line and Fuel Pump (209). Check fuel pump coupling. Check belts.
4. If nozzle pressure equals manifold pressure when the generator should be firing, check for defective Solenoid Valve (104), improper setting of or defective Servo Cut-out Switch (108). Check operation of Atomizing Air Cut-out Switch (101), Steam Temperature Limit Switch (110), or Control Switch.

3A3. Air supply system fault. No fuel spray and air pressure is below 25 PSI. perform these checks.

1. Be sure Atomizing Air Shutoff Valve #1 is **open**.
2. Check locomotive Main Air Supply Cut-off Valve to the Steam Generator.
3. Drain water from bottom of Zenith Air Filter (200).
4. Clean Air Filter elements.
5. Check for other obstructions in the air line.



3B. If generator runs normally . . .

Cause of shutdown may have been a temporary misfiring during the "ON" cycle due to Sprayhead, Spark or Damper misadjustment.

400. EMERGENCY PROCEDURES

Always place control switch in OFF position before performing any emergency set up procedure.

Before resorting to the following emergency procedures, it is important that an actual, urgent need is known to be present. These procedures are "last resort" measures to maintain passenger comfort and safety and should in no way preclude proper repair. In every case, what is done on the road should be carefully documented on the appropriate locomotive report form in order to insure complete and final repair.

401. THE WATER RETURN SIGHT GLASS BREAKS, FILLING THE STEAM GENERATOR COMPARTMENT WITH WATER AND STEAM.

- WHAT TO DO**
- (1) Close the #9 Valve. This will send wet steam into the trainline but will allow the steam generator to continue operating.
 - (2) If water level in the deck or hatch tank is above the return sight glass, water will discharge from the glass, if so plug opening with rags.

402. BOTH BELTS BREAK ON EITHER THE BLOWER OR PUMP, SHUTTING THE STEAM GENERATOR DOWN.

- WHAT TO DO**
- Remove one appropriate belt from any other steam Generator and apply it to the steam generator with missing belts.

403. THE FUEL SOLENOID VALVE WILL NOT SHUT OFF (FIRE STAYS ON).

- WHAT TO DO**
- (1) Move control switch to **Fill** in order to keep water in the coils and to electrically de-energize the fuel solenoid valve.
 - (2) Latch open #12 valve.
 - (3) Tap sides of fuel solenoid valve. This tapping may dislodge the foreign material holding the valve open.
 - (4) If still firing, turn control switch to **Off**.
 - (5) Crack open the fuel pump discharge tubing to break any siphon or keep steam generator operating in the manual mode opening the roof orifice valve if necessary.

404. BURNER SIGHT GLASS BREAKS, FILLING STEAM GENERATOR COMPARTMENT WITH COMBUSTION GASSES.

- WHAT TO DO**
- (1) Remove sight glass assembly.
 - (2) Place several layers of aluminum foil against burner at sight glass opening.
 - (3) Replace sight glass assembly over foil.

405. THE CONTROL RELAY WILL NOT ENERGIZE. (STEAM GENERATOR WILL NOT FIRE)

- WHAT TO DO**
- (1) Place Control Switch in **OFF**.
 - (2) Mechanically block Control Relay contact carrier in upward position. Control relay is in upper left hand corner of electrical cabinet.
 - (3) Place Control Switch in **Run** position.

CAUTION

Steam generator fire will not shut down automatically. Operate steam generator in the Manual Mode.

406. THE SERVO SWITCH ACTUATOR BREAKS.

- WHAT TO DO**
- If the dual spring actuator is broken on one side, the entire assembly can be removed and rotated so that the intact section will actuate the switch plunger.

407. THE SERVO MICRO-SWITCH IS DEFECTIVE.

- WHAT TO DO**
- (1) To **Fill**. Place a jumper wire between control panel terminals SS3 and CS2. This will complete the circuit to the Line Relay. Leave the jumper in place if you intend to run the steam Generator.
 - (2) To **Run** the steam Generator it is necessary to place a jumper between terminals FSV1 and FSV2; this will close the circuit for the Servo "A" switch.

CAUTION

The servo "A" switch is the low or no-water protection for the steam generator. After performing the above, it will be necessary to insure that water is actually flowing through the servo. Operate the steam generator manually.

408. THE CONTROL SWITCH KNOB BREAKS AWAY OR IS LOST.

- WHAT TO DO** (1) Use pliers or adjustable wrench to turn the switch actuator to the left for **Fill** or to the right for **Run**, or ...
- (2) A knob can be removed from another steam generator control switch and used for both units.

409. THE FUEL SOLENOID VALVE WILL NOT OPEN. (NO FUEL OIL FROM SPRAY, BUT ALL OTHER REQUIREMENTS PRESENT)

WHAT A. On "Square D" fuel solenoid valve.

- (1) Remove inlet fitting from present position at bottom of valve.
- (2) Remove brass plug from opposite side of valve.
- (3) Install inlet fitting into port left open from plug. (This port is 180° away from the original opening).
- (4) Place plug into original inlet valve port.
- (5) Reconnect fuel tubing to fitting in new valve port.

B. "ITT" Fuel Solenoid valve.

- (1) Remove 3/8" CT X 3/8" NPT 90° elbow inlet fitting to valve.
- (2) Unscrew solenoid valve and outlet nipple from spray head inlet elbow.
- (3) Fit the 3/8" CT X 3/8" NPT 90° elbow into the 3/8" spray head inlet elbow.
- (4) Reconnect the fuel tubing to the inlet fitting.

CAUTION

The above procedures outline the by-passing of the Fuel Solenoid Valve. Fuel oil will now be fed to the spray head and ignited in either the **FILL** or **RUN** modes. **BE SURE THE COILS ARE FILLED WITH WATER BEFORE THIS BY-PASS PROCEDURE IS USED.** The steam generator must be operated in the **MANUAL MODE**.

410. THE CONTROL SWITCH IS SUSPECTED OF BEING DEFECTIVE IN ANY OF ITS THREE CIRCUITS.

- WHAT TO DO** (1) Refer to Steam Generator Electrical drawing in Section 500. Figure 500-2.
- (2) Circuit 1 failure—the Line Relay Coil will not pick up. Connect a "jumper" wire from CB2 (located on Electrical Cabinet terminal board) to the left side

(+) of the Line Relay Coil. If the control switch is at fault the Line Relay should pick up.

- (3) Circuit 2 failure—the Fuel Solenoid Valve Circuit. Connect a "jumper" wire from SS2 terminal to FSV2 terminal on the Electrical Cabinet terminal board. If switch is at fault the Steam Generator should "light off".
- (4) Circuit 3 failure—the Outfire Relay Circuit. Connect a "jumper" wire from terminal CS to terminal SS3 located on the Electrical Cabinet terminal board. If the switch is at fault the Steam Generator should operate.

411. IGNITION SPARK IS LOST.

Perform these ten simple, safe steps:

- WHAT TO DO** (1) Refill the coils with water as outlined in the Filling Procedure (Section 101). Be sure to operate the steam generator in the **Fill** mode for at least 3 minutes to evacuate any unburned gasses and cool the steam generator as much as possible.
- (2) Move control switch from **Fill** to **Off** and manually position the servo "bow-tie" to the **Off** position (left side down).
- (3) Close #19 valve.
- (4) Loosen the burner sight glass and move it to one side.
- (5) Light a fusee in the following manner:

LIGHTING A FUSEE

- (a) Hold fusee in your left hand.*
- (b) Peel away the tape securing the cap to the body of the fusee. Remove the cap.
- (c) Remove the tape completely from the cap of the fusee, exposing its striking surface located on the outer center of the cap. Hold the cap with right hand* with striking surface towards the fusee.
- (d) Be sure no other person is standing near you.
- (e) Place the striker area of the cap against the top of the fusee.
- (f) Sharply press the striker portion of the cap against the top of the fusee and rub forward (away from you) all in one motion. The fusee should light. If not, repeat steps (e) and (f) until lit.

- (g) Keep the lit fusee at arm's length, below the shoulder. Move it slowly.

**If left-handed, reverse the holding position in steps A and C.*

- (6) Place the lit fusee into the burner sight glass opening with the burning end as close to the front spark plug electrode as possible.
- (7) Move the Control Switch to **Run**. The fusee should ignite the oil spray immediately. If it does not, repeat steps 1, 2 and 6.
- (8) Once ignition has started, remove the fusee from the burner assembly and extinguish it properly as follows:

EXTINGUISHING A FUSEE

Extinguish the fusee by striking its lit portion lightly over a solid object until the lit portion drops off. **Do not** allow the lit portion to contact combustible material: (oil, grease, paper, wood etc.).

CAUTION

Once lit, the fusee will continue burning for 15-20 minutes if not extinguished. **Do not** throw a lit fusee from a moving train, since the track will be closed to following traffic until the fusee burns itself out. Another danger is that brush fires could be started along the right-of-way.

- (9) Swing the sight glass assembly to its **closed** position.
- (10) Operate the steam generator in the **Manual Mode** by opening and closing the #8 valve to control trainline pressure.

NOTE: If the #8 valve is opened too much, the "Bow-Tie" will move to the OFF FIRE Position and the manual lighting procedure must be repeated.

412. THE HEAT EXCHANGER BEGINS LEAKING, CAUSING THE STEAM TEMPERATURE LIMIT SWITCH TO TRIP.

WHAT TO DO

- (1) Close the #81 and insure that #82 valve is also closed.
- (2) Continue running; this will allow excessive water to enter the trainline, but will do no harm to the steam generator.

413. THE STEAM GENERATOR IS EXTREMELY SOOTED. STACK SWITCH HIGH TEMPERATURE RESET ACTUATES.




WHAT TO DO

- (1) Correct the cause for sooting before doing anything else. (Stuck damper, broken belts, no atomizing air, etc.)
- (2) **Fill** coils with water as outlined in Section 101.
- (3) Place Control switch in **Run** position.
- (4) Once lit, move Control Switch to **Fill**. If coils are severely sooted, the fire will remain on. When fire goes out it means that excessive amounts of soot are burned off.
- (5) Move Control switch to **Run** and operate steam generator in **Manual** mode.
- (6) If Stack Switch continues to trip, remove stack switch whenever temperature indicator reaches the 1-2 o'clock trip position. When the temperature indicator drops to the 9 o'clock position re-insert the stack switch and repeat as many times as necessary until reaching a maintenance point.

414. THE CONTROL OR TRANSFORMER FUSES BLOW AND NO REPLACEMENTS ARE AVAILABLE.

WHAT TO DO

- (1) Open Circuit Breaker or Main switch.
- (2) Examine all appliance cords for bare wires causing a short circuit. Repair such wires if possible with cardboard, paper towels or any other suitable material.
- (3) Wrap the defective fuse with aluminum foil, or metal-coated chewing gum wrappers.
- (4) Re-install fuse in clips and close main switch or circuit breakers. (Thin-gauge wire can also be used across the fuse clips). As a last resort, 3/8" copper tubing can also be used as a temporary jumper across the fuse clips.



LEGEND

SYMBOL	DESCRIPTION
[Symbol]	1 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/2 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/4 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/8 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/16 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/32 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/64 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/128 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/256 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/512 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1024 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/2048 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/4096 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/8192 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/16384 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/32768 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/65536 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/131072 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/262144 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/524288 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1048576 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/2097152 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/4194304 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/8388608 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/16777216 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/33554432 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/67108864 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/134217728 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/268435456 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/536870912 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1073741824 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/2147483648 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/4294967296 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/8589934592 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/17179869184 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/34359738368 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/68719476736 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/137438953472 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/274877907344 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/549755814688 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1099511629376 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/2199023258752 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/4398046517504 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/8796093035008 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/17592186070016 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/35184372140032 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/70368744280064 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/140737488560128 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/281474977120256 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/562949954240512 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1125899908481024 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/2251799816962048 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/4503599633924096 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/9007199267848192 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/18014398535696384 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/36028797071392768 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/72057594142785536 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/144115188285571072 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/288230376571142144 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/576460753142284288 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1152921506284568576 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/2305843012569137152 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/4611686025138274304 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/9223372050276548608 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/18446744100553097216 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/36893488201106194432 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/73786976402212388864 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/14757395280442477728 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/29514790560884955456 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/59029581121769910912 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/118059162243539821824 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/236118324487079643648 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/472236648974159287296 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/944473297948318574592 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1888946595896637149184 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/3777893191793274298368 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/7555786383586548596736 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/15111572767173097193472 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/30223145534346194386944 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/60446291068692388773888 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/120892582137384777547776 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/241785164274769555095552 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/483570328549539110191104 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/967140657099078220382208 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1934281314198156440764416 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/3868562628396312881528832 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/7737125256792625763057664 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/15474250513585251526115328 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/30948501027170503052230656 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/61897002054341006104461312 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/123794004108682012208922624 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/247588008217364024417845248 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/495176016434728048835690496 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/990352032869456097671380992 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1980704065738912195342761984 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/3961408131477824390685523968 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/7922816262955648781371047936 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/15845632525911297562742095872 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/31691265051822595125484191744 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/63382530103645190250968383488 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/126765060207290380501936766976 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/253530120414580761003873533952 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/507060240829161522007747067904 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1014120481658323044015494135808 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/2028240963316646088030988271616 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/4056481926633292176061976543232 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/8112963853266584352123953086464 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/16225927706533168704247906172928 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/32451855413066337408495812345856 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/64903710826132674816991624691712 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/129807421652265349633983249384224 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/259614843304530699267966498768448 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/519229686609061398535932997536896 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1038459373218122797071865995073792 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/2076918746436245594143731990147584 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/4153837492872491188287463980295168 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/8307674985744982376574927960590336 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/16615349971489964753149855121180672 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/33230699942979929506299710242361344 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/66461399885959859012599420484722688 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/132922799771919718025198840969445376 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/26584559954383943605039768193890752 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/53169119908767887210079536387781504 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/106338239817535774420159072775563008 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/212676479635071548840318145551126016 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/425352959270143097680636291102252032 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/850705918540286195361272582204504064 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1701411837080572390722545164409008128 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/3402823674161144781445090328818016256 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/6805647348322289562890180657636032512 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/13611294696644579125780361315272065024 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/27222589393289158251560722630544130048 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/54445178786578316503121445261088260096 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/108890357573156633006242890522176520192 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/217780715146313266012485781044353040384 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/435561430292626532024971562088706080768 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/871122860585253064049943124177412161536 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1742245721170506128099886248354824323072 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/3484491442341012256199772496709648646144 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/6968982884682024512399544993419297292288 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/13937965769364049024798889986838594584576 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/27875931538728098049597779973677189169152 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/55751863077456196099195559947354378338304 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/111503726154912392198391119894708756676608 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/223007452309824784396782239789417513353216 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/446014904619649568793564479578835026706432 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/892029809239299137587128959157670053412864 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1784059618478598275174257918315340106825728 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/3568119236957196550348515836630680213651456 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/7136238473914393100697031673261360427302912 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/14272476947828786201394063346522720854605824 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/28544953895657572402788126693045441709211648 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/57089907791315144805576253386090883418423296 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/114179815582630289611152506732181766836846592 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/228359631165260579222305013464363533673693184 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/456719262330521158444610026928727067347386368 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/913438524661042316889220053857454134694772736 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1826877049322084633778440107714908269389545472 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/3653754098644169267556880215429816538779090944 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/7307508197288338535113760430859633077558181888 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/14615016394576677070227520861719266155116337792 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/29230032789153354140455041723438532310232675584 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/58460065578306708280910083446877064620465351168 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/116920131156613416561820166893754129240930702336 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/233840262313226833123640333787508258481861404672 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/467680524626453666247280667575016516963722809344 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/935361049252907332494561335150033033927445618688 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1870722098505814669989122670300066067854891237376 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/3741444197011629339978245340600132135709782474752 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/7482888394023258679956490681200264271419564949504 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/14965776788046517359912981362400528542839129899008 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/29931553576093034719825962724801057085678259798016 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/59863107152186069439651925449602114171356519596032 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/119726214304372138879303850899204228342713039192064 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/239452428608744277758607701798408456685426078384128 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/478904857217488555517215403596816913370844156768256 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/957809714434977111034430807193633826741688313536512 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1915619428869954222068861614382667653483376627073024 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/3831238857739908444137723228765335306966753254146048 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/7662477715479816888275446457530670613933506508292096 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/15324955430959633776550892915061341227867013016584192 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/30649910861919267553101785830122682455734026033168384 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/61299821723838535106203571660245364911468052066336768 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/122599643447677070212407143320490729822936104132673536 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/245199286895354140424814286640981496445872208265347072 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/490398573790708280849628573281962992891744416530694144 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/980797147581416561699257146563925985783488833061388288 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/1961594295162833123398514291127851971566977666122776576 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/3923188590325666246797028582255703943133955332245553152 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/7846377180651332493594057164511407886267910664491106304 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/15692754361302664987188114329022815772535821328982212608 IN. DIA. STEEL DISCHARGE PIPING
[Symbol]	1/31385508722605329974376228658045631545071642657964425216 IN. DIA. STEEL DISCHARGE PIPING

STEAM GENERATOR VALVE POSITION GUIDE

VALVE NAME & NUMBER	FILL	RUN	MANUAL OPERATION	SHUT DOWN	COLD WEATHER PROTECTION	NOTES
ATOMIZING AIR #1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	(A) OPEN until steam pressure drops to 100 PSI, then CLOSE.
COIL BLOW-DOWN #2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/> (A)	<input checked="" type="checkbox"/>	(B) MANUALLY regulate to control steam pressure.
FILL TEST #4	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	(C) Must be CLOSED to prevent possibility of tripping steam temperature limit switch.
MANUAL BY-PASS #8	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> (B)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	(D) OPEN during startup, CLOSE when steam pressure is 100 PSI.
STEAM ADMISSION TO GENERATOR #10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> (C)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	(E) CLOSE until steam pressure drops to 100 PSI, then OPEN.
SEPARATOR BLOW-DOWN #12	<input checked="" type="checkbox"/>	<input type="checkbox"/> (D)	<input checked="" type="checkbox"/>	<input type="checkbox"/> (E)	<input checked="" type="checkbox"/>	(F) May be CRACKED to prevent generator from short-cycling or water-logging.
TRAINLINE SHUT OFF #15	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	(G) MUST BE FULLY OPEN during orifice test. If the generator is operating, it should maintain 180-240 PSI.
WATER PUMP TEST #18	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
WATER BY-PASS REGULATOR SHUT-OFF #19	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
ROOF ORIFICE NO #	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> (F) <input type="checkbox"/> (G)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
The following valves MUST remain in the position indicated EXCEPT for certain maintenance procedures:						
COIL SHUT OFF #3	<input type="checkbox"/>					
RETURN WATER OUTLET #9	<input type="checkbox"/>					
STEAM SHUT-OFF TO WATER BY-PASS REGULATOR #13	<input type="checkbox"/>					
SUCTION SHUT-OFF #21	<input type="checkbox"/>					
WATER RETURN WASH-OUT SHUT OFF #81	<input type="checkbox"/>					
		WASH-OUT SHUT-OFF #14				
		WATER PUMP SUCTION DRAIN #20				
		ALL DRAIN VALVES #26				
		WATER RETURN DUMP VALVE #82				

- (A) OPEN until steam pressure drops to 100 PSI, then CLOSE.
- (B) MANUALLY regulate to control steam pressure.
- (C) Must be CLOSED to prevent possibility of tripping steam temperature limit switch.
- (D) OPEN during startup, CLOSE when steam pressure is 100 PSI.
- (E) CLOSE until steam pressure drops to 100 PSI, then OPEN.
- (F) May be CRACKED to prevent generator from short-cycling or water-logging.
- (G) MUST BE FULLY OPEN during orifice test. If the generator is operating, it should maintain 180-240 PSI.
- * AMTRAK STANDARD is the single-valve (#10 only) cold weather protection system; this valve must be positioned as shown in the valve guide.
- Some generators are equipped with a two-valve system (#6 as well as #10); on such generators, position the valves as follows:
- #6 CLOSED during operation to prevent tripping steam temperature limit switch; OPEN in cold weather when generator is shut down.
- #10 May be CRACKED while generator is operating in cold weather. MUST BE OPEN when generator is shut down in cold weather.

LEGEND

- ☒ Indicates CLOSED.
- ☒ Indicates CRACKED or PARTIALLY OPENED.
- ☐ Indicates OPEN.

FIGURE 500-3. STEAM GENERATOR VALVE POSITION GUIDE

1. ELECTRODE & FUEL SOLENOID VALVE WIRES
2. IGNITION TRANSFORMER
3. FUEL PRESSURE REGULATOR
4. FUEL MANIFOLD PRESSURE GAUGE
5. ELECTRICAL CONTROL CABINET
6. WATER RELIEF VALVE
7. #18 VALVE
8. WATER PRESSURE GAUGE
9. SAFETY VALVES
10. DAMPER INDICATOR
11. FUEL STRAINER
12. ATOMIZING AIR PRESSURE SWITCH
13. FUEL NOZZLE PRESSURE GAUGE
14. DAMPER ACTUATING RODS
15. SELECTOR SWITCH "FILL-OFF-RUN"
16. #19 VALVE
17. MOTOR-CONVERTER
18. FUEL PUMP
19. DIP STICK
20. WATER PUMP
21. RADIATION COIL
22. ACID SOLUTION INLET WHEN SG PUMP IS USED
23. #81 VALVE
24. #82 VALVE
25. ATOMIZING AIR PRESSURE GAUGE
26. #15 VALVE
27. SOL. VALVE FOR AEB-53
28. AUTO. BLOWDOWN TIMER ASSY. (AEB-53)
29. #15 VALVE CONTROLLER "SHUT-OPEN"
30. SERVO SWITCHES
31. SERVO CONTROL "BOW TIE"
32. SERVO FUEL METERING VALVE
33. RETURN WATER SIGHT GLASS
34. WBR DELAY ADAPTER
35. WATER-BY-PASS REGULATOR (WBR)
36. STEAM TRAP
37. WBR SELECTOR HANDLE
38. #8 VALVE
39. #4 VALVE
40. OUTLET OF INNER COIL
41. FUEL SUCTION FILTER




FIGURE 10-1. OK-4625-74 RIGHT HAND STEAM GENERATOR (FRONT VIEW)

1. AEB-53 AUTO BLOWDOWN CONTROL
2. SERVO
3. WATER-BY-PASS REGULATOR
4. #82 VALVE
5. FEEDWATER INLET
6. PRIMARY FUEL FILTER
7. TRAP STRAINER
8. ACID INLET #14 VALVE
9. FUEL PUMP
10. TRAP
11. HEAT EXCHANGER
12. AIR INTAKE HOUSING
13. AUTOMATIC TRAINLINE SHUTOFF VALVE #15
14. FUEL SOLENOID VALVE
15. BURNER ASSY.
16. SPARK PLUGS
17. SAFETY VALVES
18. AIR DOME ASSY.
19. STEAM TEMP LIMIT SWITCH
20. FEEDWATER INLET TO COILS
21. CHECK VALVES
22. STACK OUTLET
23. LAYOVER STEAM INLET (FROM #10 VALVE)
24. #3 VALVE
25. ACID INLET FROM MANIFOLD
26. OUTER COIL INLET
27. SMOKE HOOD
28. ECONOMIZER COIL OUTLET
29. #2 COIL BLOWDOWN VALVE
30. UPPER CASING ASSY.
31. BASE ASSY.




FIGURE 10-2. OK-4625 LEFT-HAND STEAM GENERATOR (RIGHT SIDE VIEW)

1. STACK SWITCH
2. #10 VALVE
3. #2 VALVE (COIL BLOWDOWN)
4. STEP RAIL
5. BASE ASSY DRAIN PLUG
6. ACID OUTLET
7. SEPARATOR
8. ROOF ORIFICE VALVE PLUG
9. AUTOMATIC TRAINLINE SHUTOFF VALVE (#15)
10. #13 VALVE
11. AUTOMATIC TRAINLINE VALVE (#15) CONTROLLER
12. OPEN
13. SHUT
14. PRESSURE GAUGE (FOR VAPOR T/L VALVE ONLY)
15. STEAM PRESSURE GAUGE
16. BLOWER SHAFT OPENING
17. BELT TENSION ADJUSTER OPENING
18. #9 VALVE
19. BELT COVER
20. MOTOR-CONVERTER SHAFT OPENING
21. WATER PUMP SHAFT OPENING
22. SEPARATOR BLOW-DOWN VALVE AND PEDAL




FIGURE 10-3 OK-4625-74 LEFT-HAND STEAM GENERATOR (LEFT SIDE VIEW)

1. DOME ASSEMBLY
2. #3 VALVE
3. ECONOMIZER COIL INLET
4. SMOKE STACK CONNECTING FLANGE
5. LIFTING EYE
6. ECONOMIZER COIL OUTLET
7. OUTER COIL OUTLET
8. COIL INSPECTION DOOR CLAMP
9. SEPARATOR
10. STACK SWITCH
11. #10 VALVE
12. COIL INSPECTION DOOR CLAMP
13. INNER COIL INLET
14. INTERMEDIATE COIL OUTLET
15. #2 VALVE
16. INTERMEDIATE COIL INLET




FIGURE 10-4. OK-4625-74 LEFT-HAND STEAM GENERATOR (REAR VIEW)

NATIONAL RAILROAD PASSENGER CORPORATION
INTEROFFICE MEMO

DATE: May 24, 1978

TO: TO ALL HOLDERS OF STEAM GENERATOR
OPERATING MANUAL VAPOR OK-4625-74

FROM: J.F. Roseman


SUBJECT: Corrections to Steam Generator
Operating Manual

Enclosed are corrected Figure 500-1 Steam Generator Piping Diagram and Figure 500-2 Electrical Schematic drawing. Please substitute these in your book.

In addition, add to section 10, General Specification Data (page 3) the following:

Fuel nozzle pressure 15-60 PSI depending on load.

Spark Gap 3/16".


J.F. Roseman


SDP40 Cold Weather Protection Systems

To Coils



SDP40 One-Valve Cold Weather Protection System







To Coils



SDP40 Two-Valve Cold Weather Protection System



ELECTRICAL CABINET



OPERATING POSITION	
UP	DOWN
1	2
3	4
5	6
7	8
9	10
11	12
13	14
15	16
17	18
19	20
21	22
23	24
25	26
27	28
29	30
31	32
33	34
35	36
37	38
39	40

LEGEND
 1. TOP LEFT SYMBOL
 2. TOP RIGHT SYMBOL
 3. BOTTOM LEFT SYMBOL
 4. BOTTOM RIGHT SYMBOL
 5. POWER SWITCHES





FIGURE 500-2. ELECTRICAL SCHEMATIC DRAWING